

Parametri za setovanje skenera Metrologic MS-6220 sa registar kasom Mikro

Enter/Exit Configuration Mode



Recall Defaults



Enable RS-232.



No Parity.



9600 BAUD Rate



8 Data Bits.



1 Stop Bit.



Enter/Exit Configuration Mode

