

ScanPlus 1800 – Sharp ER-457S/F

reset factory defaults



\46\42\60

predefined terminal selections - RS-232 - special RS-232 configurations - TTL logical 0 = 0V (9600,



\41\4A\01\24\60

RS-232 - baud rate - 4800



\41\06\60

RS-232 - data bits - 7 (*)



\42\60

RS-232 - parity - odd



\46\02\60

RS-232 - stop bits - 2 (*)



\45\60

RS-232 - preamble - compose: <STX>



\45\53\3E\02\60

RS-232 - symbology identifier - custom - transmitted



\45\55\60